

# SERVICE BULLETIN

NUMBER 510

10/29/10

EPC Logic Assembly  
681064-1

Older iterations of the EPC Logic Assembly require a jumper for proper connection on single-bank applications. The EPC-100E, however, does not require a jumper and the terminals formerly used for the jumper have been redesignated as shown below.

Using a jumper on the newer board will cause an AUTO ENGINE OFF error. This new connection allows a REMOTE F1 START to be executed by a momentary connection from this input to the COMMON GND.

**THE EPC-100E MUST USE A MENU SELECTION TO SELECT SINGLE OR DUAL BANK OPERATION.**

